

# KOMP PCR Design

Mouse PCR Protocol (version 1)

Design ID: 213687

Project ID: CSD33386

Selection Cassette: L1L2\_Bact\_P



MMRRC Stock #: 046545-UCD

C57BL/6N-Atm1Brd AI464131tm1b(KOMP)Wtsi/  
JMmucd

## Suggested DNA Prep: DNeasy®Tissue Kit


Reagent	1X (μL)
water (biological grade)	10.725
betain 5M (Sigma)	6.5
DMSO (Sigma)	0.325
10X buffer w/o MgCl <sub>2</sub> (AB)	2.5
25 mM MgCl <sub>2</sub> (AB)	1.75
10 mM dNTPs (Invitrogen)	0.5
primers (20 μM each)	0.5
Taq 5U/μL (AmpliTaq, AB)	0.2
total cocktail	23
template	2
reaction volume	25

Cycling Parameters	
Temperature °C	Time
94	5 min
94	15 sec
65	30 sec
72	40 sec
94	15 sec
55	30 sec
72	40 sec
72	5 min
4	finished

**10X (decrease 1°C/cycle)**

**30X**

## Primer Strategy



## Cassette Primers

CSD-lacF: GCTACCATTACCAGTTGGTCTGGTGTC  
 CSD-neoF: GGGATCTCATGCTGGAGTTCTTCG  
 CSD-loxF: GAGATGGCGCAACGCAATTAATG

## Gene Specific Primers

CSD-AI464131-R: TTTCTGCAGACTGAAGTGAATGGGC  
 CSD-AI464131-ttR: ACTTACTCTCGTTTCTCTCAGGCC  
 CSD-AI464131-F: CTCTGTGACTGAATGTGGCTTTGGG

Genotype	Forward Primer	Reverse Primer	Amplicon size (bp)
Floxed	CSD-loxF	CSD-AI464131-R	228
PreCre	CSD-neoF	CSD-AI464131-ttR	594
PostCre	CSD-lacF	CSD-AI464131-R	526
Wildtype	CSD-AI464131-F	CSD-AI464131-ttR	517
PostFlp	CSD-AI464131-F	CSD-AI464131-ttR	679
PostFlp & Cre	CSD-AI464131-F	CSD-AI464131-R	606

Please note, these primers are auto-designed and may not have been verified by the repository, and as such may require optimization or redesign by your facility.

We recommend running primers singleplex. For screening of pups prior to any Flp or Cre recombination, the Floxed or PreCre primers may be used to identify the mutant mice. The Floxed primers test for the distal LoxP site. The PostCre primers should be used if mutant mice were crossed with a Cre recombinase line (without any FLP recombination). The PostFlp primers should be used if mutant mice were crossed with a Flp recombinase line. The PostFlp & Cre primers should be used if mutant mice were crossed with a Flp recombinase line and then a Cre recombinase line. The wildtype primers should be used for zygosity testing of all mutant mice (pre or post recombination).