KOMP PCR Design

Mouse PCR Protocol (version 1BW)

Design ID: 48449 Project ID: CSD23053

Selection Cassette: L1L2_Bact_P




MMRRC Stock #: 048346-UCD

C57BL/6N-KIhl8tm1a(EUCOMM)Wtsi/Mmucd

Suggested DNA Prep: DNeasy®Tissue Kit

Reagent water (biological grade)	1Χ (μ L) 10.725	Cycling Parameters	Time	
betain 5M (Sigma)	6.5	Temperature °C 94	Time 5 min	
DMSO (Sigma)	0.325	94	15 sec	
10X buffer w lo MgCl ₂ (AB)	2.5	65	30 sec	10X (decrease 1°C/cycle)
25 mM MgCl ₂ (AB)	1.75	72	40 sec	ion (accidace i creyele)
10 mM dNTPs (Invitrogen)	0.5	94	15 sec	
primers (20 µM each)	0.5	55	30 sec	30X
Taq 5U/μL (AmpliTaq, AB) total cocktail	0.2 23	72	40 sec	
template	23	72	5 min	
reaction volume	25	4	finished	

Primer Strategy



Cassette Primers

CSD-lacF: GCTACCATTACCAGTTGGTCTGGTGTC
CSD-neoF: GGGATCTCATGCTGGAGTTCTTCG

CSD-loxF: GAGATGGCGCAACGCAATTAATG

Gene Specific Primers

CSD-*Klhl8*-R: CATGCACAAAGTGCTAGGTTTCACC CSD-*Klhl8*-ttR: GACTCATGTTCGTAAGCCCAGAACC

CSD-Klhl8-F: cagcccttaggagataaggataggac

Geneotype Forward Primer Reverse Primer Amplicon size (bp)

Floxed	CSD-loxF	CSD- <i>KIhI8</i> -R	264
PreCre	CSD-neoF	CSD- <i>Klhl8</i> -ttR	528
PostCre	CSD-lacF	CSD- <i>KIhI8</i> -R	562
Wildtype	CSD-Epn3-F	CSD- <i>Klhl8</i> -ttR	268
PostFlp	CSD-Epn3-F	CSD- <i>Klhl8</i> -ttR	407
PostFlp & Cre	CSD-Epn3-F	CSD- <i>KIhI8</i> -R	490

Please note, these primers are auto-designed and may not have been verified by the repository, and as such may require optimization or redesign by your facility.

We recommend running primers singleplex. For screening of pups prior to any Flp or Cre recombination, the Floxed or PreCre primers may be used to identify the mutant mice. The Floxed primers test for the distal LoxP site. The PostCre primers should be used if mutant mice were crossed with a Cre recombinase line (without any FLP recombination). The PostFlp primers should be used if mutant mice were crossed with a Flp recombinase line. The PostFlp & Cre primers should be used if mutant mice were crossed with a Flp recombinase line and then a Cre recombinase line. The wildtype primers should be used for zygosity testing of all mutant mice (pre or post recombination).